

## Koshi batten detail


### Profile: Nami Plank 100x10 (square edge)

Weight: 0.654 kg/m



Batten thickness: 1.0mm





End cap thickness: 2.0mm

End cap: Coloured ABS plastic



### Endcap detail



		Product Name				Project Name		Date	Page	Scale	Projection
		KOSHI NAMI PLANK 100X10						07/2021	1 of 3	1:1	
	Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.		Approval	Check	Drawing	Design	 <div style="display: flex; justify-content: space-between;"> <div> <p>Melbourne Showroom 2 Ginibi Drive Altona North VIC 3025</p> </div> <div> <p>T +613 9398 8128 info@covet.com.au www.covet.com.au</p> </div> </div>			
	End Caps	Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.									

## Koshi batten detail


### Profile: Nami Plank 150x10 (square edge)

Weight: 0.952 kg/m


Batten thickness: 1.0mm





End cap thickness: 2.0mm

End cap: Coloured ABS plastic








### Endcap detail



		Product Name				Project Name		Date	Page	Scale	Projection
		KOSHI NAMI PLANK 150X10						07/2021	2 of 3	1:1	
	Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.		Approval	Check	Drawing	Design	 <div style="display: flex; justify-content: space-between;"> <div> <p>Melbourne Showroom 2 Ginibi Drive Altona North VIC 3025</p> </div> <div> <p>T +613 9398 8128 info@covet.com.au www.covet.com.au</p> </div> </div>			
	End Caps	Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.									

## Koshi Batten Installation Guide

- Aluminium can be damaged if mishandled. Never strike directly with a hammer or rubber mallet. Use a pine plank between the striking rubber mallet and the extrusion to avoid surface damage or denting.
- Cut aluminium with a drop saw using an aluminium blade.
- Always cap ends of extrusions with supplied end caps or a flashing to avoid moisture ingress.
- Metal end caps (painted) must be screwed to the extrusion.
- All end caps can only be applied to straight 90 degree cuts. They cannot be applied to angle end cuts.
- Ensure appropriate screws are used to suit the substrate you are fastening to. It is important to use stainless steel or bi-metal screws for all metal surfaces impacted when fastening (i.e. furring channels, top hats, steel frames). This will prevent galvanic reaction between the screw/substrate and aluminium extrusion.
- Fasten at maximum 1 metre spans. Please contact Covet for further information.

		Product Name				Project Name	Date	Page	Scale	Projection
		KOSHI NAMI PLANKS					07/2021	3 of 3		
										
	Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.	Approval	Check	Drawing	Design			Melbourne Showroom 2 Ginibi Drive Altona North VIC 3025	
	End Caps	Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.								